

## Content

CT-5801 Terminal module (Required) .....	2
1 Module Description .....	2
2 Technical Parameters .....	2
3 Hardware Interface .....	2
A Dimension drawing .....	3

## CT-5801 Terminal module (Required)

### 1 Module Description

The terminal module is used to stabilize internal bus communication and it is required.


The terminal module CT-5801 has no process data and no configuration parameters.

CT-5801 requires no configuration and occupies no slot in configuration.

### 2 Technical Parameters

None

### 3 Hardware Interface



① Module Type

③ Internal Bus

④ Buckle

- ⑤ Grounding Resilient Sheet
- ⑥ Terminal Cover

### 3.1 LED indicator definition

None

### A Dimension drawing

